

Hybrid Hydraulic System
“Super Unit”

SUT00D4016
SUT00D6021

Instruction Manual



DAIKIN INDUSTRIES, LTD

油機事業部

Oil Hydraulics Division

DAIKIN INDUSTRIES, LTD.

《SAFETY PRECAUTIONS》

Before Usage

- To ensure to notify these contents of this document for user.
 - Add this contents to your machine's handling manual which uses this product.
- Before installation, operation or maintenance, read thoroughly this handling manual and other attached documents and learn equipments knowledge, safety information and attentions, then use this product properly.
- To ensure keeping this manual, attached documents and supply specifications and so on, whenever user enable read these documents.
- So all figure or photo in this manual are sometimes drawn the state of removing the cover or safety insulate object to explain details, which you operate surely put the cover or insulate object as it was before and operate following this manual.
- This manual may be changed for improvement of the product or alteration of specifications or improve this manual more easily. As for the hydraulic division internet service (DHCnet Homepage) (<http://www.dhcnet.co.jp:8100/>)
- This document is about safety handling of our hydraulic unit. Prepare date for safety handling according to the standard for safety operation or maintenance of your machine.

Symbols of safety precautions in this manual

- In this manual, safety precautions are represented and classify 3 rank, “▲ Danger”, “▲ Warning” and “▲ Caution”.

▲ Danger: If you ignore this symbol and handle improperly, it may pose a high risk of causing death or serious injury.

▲ Warning: If you ignore this symbol and handle improperly, it may pose the risk of causing death or serious injury.

▲ Caution: If you ignore this symbol and handle improperly, it may pose the potential risk of causing injury or damage to the product or property.

Although the matter is mentioned in “▲ Caution” symbol, there will cause serious result. Be sure to observe these precautions.

Safety

General

▲ Danger

- Qualified people perform the task such as transportation, installation, piping, wiring, operation, handling, maintenance, and inspection.
- When working, make use of protective tools (uniform, safety belt, helmet, safety shoes, gloves, etc).
- Do not use another specifications which is mentioned in the catalog, or delivery specifications.

▲ Caution

- Be sure to enforce daily inspection (it is mentioned in this document, or in attached document.)
- Do not stand, beat or add pressure on the products, or you may be injured and the product is damaged.

《Exemption Clause》

- Damages owing to earthquake, fire, and action of the third party, other accidents, intentional or negligence, misuse of customers, use under unusual conditions we would exempt from any responsibilities.
- Incidental damages (loss of business profit, business suspension) owing to usage of this product, or impossibility of usage, we would exempt from any responsibilities.
- Accidents and damages caused by disobeying manuals or supply specifications, we would exempt from any responsibilities.
- Damages caused by wrong working owing to combination of connecting equipment, we would exempt from any responsibilities.

《Limitation of uses》

- Make sure to consider the situation, in case of life threatening owing to breakdown or wrong working of this machine, or possibilities of danger to the human body.
- Though, this product manufactured under strict quality control, in case of using important equipment, to prevent serious accident or damage from failure of this machine, install safety equipment.

- Table of contents -

【1. Preface】	- - - - -	5
【2. Feature and construction】	- - - - -	5 ~ 6
【3. Nomenclature】	- - - - -	7
【4. Specifications and operating conditions】	- - - - -	8
【5. Attention to use】	- - - - -	9
【6. Name of Parts】	- - - - -	10
【7. Hydraulic circuit】	- - - - -	11 ~ 12
Hydraulic circuit		
Parts		
Piping		
【8. Points for transporting, moving, and installing】	- - - - -	13 ~ 14
Operating		
Transporting		
Installation		
【9. Preparation for operation】	- - - - -	15 ~ 20
Electric Wiring		
Input and output signal specification		
【10. Test run】	- - - - -	21
【11. Operating manual of the control panel】	- - - - -	22 ~ 33
(Main points for setting the rate of flow and the pressure)		
General description		
Explanation of each mode		
Shift to each mode		
Operation manual of each mode		
a) Monitor mode		
b) Set up mode		
c) Alarm mode		
The indication list of alarm code		
【12. Maintenance】	- - - - -	34 ~ 49
【Attached Document : Points for adjusting the high pressure safety valve】	- - - - -	40
【Attached Document : Power on and the time chart of the alarm】	- - - - -	41 ~ 46
【Attached Document : Common for the input signal of the external I/O signal】	- - - - -	47

【1. Preface】

Thank you for choosing the “SUPER UNIT” series of IPM motor driven hydraulic unit from DAIKIN. IPM motor driven hydraulic unit “SUPER UNIT” realized overwhelming energy-saving and high function by adopting hydraulic technology and the energy-saving IPM motor driven system of our own development. When using “SUPER UNIT: SUT series”, manage proper handling and maintenance after reading this manual thoroughly to cross for a long time and to keep good performance. Approve it in case the contents of this manual are sometimes partly different from the product because of the change of the parts according to the improvement of quality, performance and other circumstances.



【2. Feature and Construction】

(1) Energy-saving

The energy efficiency of the motor promotes by adopting the high efficiency IPM motor driven system of our own development.

The self-controlled solenoid operated dual pump system to control to changeover joining / dividing flow corresponding to the load pressure by using the fixed displacement dual pump of the low flow and the high flow and the diverter valve.

In case high flow is necessary, drive high-speed revolution join with dual fixed displacement pump of the low flow and the flow, and in case high flow is unnecessary, as keeping pressure, drive low-speed revolution only the low flow pump side. So the great energy saving has been realized.




(2) Multiple speed and multiple pressure control and shock-less control function have loaded.

Multiple pressure and flow control are available by choosing (input the contact point) the PQ characteristic of 4 patterns set up in the controller in advance from the main machine.

Set and adjust the increase/reduce time as for P characteristic, and acceleration/deceleration time as for Q characteristic in changeover make shock-less control possible.

Since it controls with not the valve as usual, but the pump, simplify the system and reduce costs when high/low speed switching such as press machine and multiple pressure control.



【3. Nomenclature】

(a)	(b)	(c)	(d)		(e)		(f)		(g)		(h)
SUT				L		-		-		-	

(a) Series name

- SUT : SUT series

(b) Tank capacity

- 00 : tankless

(c) Pump type

- D : dual geared pump

(d) Max. discharge flow rate of the pump

- 40 : 41.0 L/min.
- 60 : 61.1 L/min.

(e) Max. working pressure

- 16 : 15.7MPa
- 21 : 20.6MPa

(f) Design No

- Progress according to the product has been changed.

(g) Noise filter specification

- F : With noise filter

(h) Non-standard No

M F G . N o

(i)	(j)	(k)		(l)
			-	-



(i) Design No

(k) Software changed history

(j) Hard ware changed history

(l) Cereal No

《Output characteristic》



【4. Specifications and Operating conditions】

Specifications

		SUT00D4016	SUT00D6021
Max. working pressure	(MPa)	15.7	20.6
Max. discharge flow rate (Note 1)	(L/min)	41.0	61.1
Pressure Adjusting range	(MPa)	1.5 ~ 15.7	1.5 ~ 20.6
Discharge rate adjusting range (Note 1)	(L/min)	5.4 ~ 41.0	8.7 ~ 61.1
Power Source (Note2)		3 200 V/50 Hz 200V/60 Hz 220V/60 Hz	
Input Signal		(3ch) Photo-coupler insulation, DC24V (Max.27V) 5mA/1ch	
Signal Output	Alarm output	(1ch) Relay output Contact capacity : DC30V 0.5A (load resistance) 1c contact	
	Warning output	(1ch) Photo-coupler insulation, open-collector output	
	Pressure switch output	(1ch) DC24V less than 30mA/1ch	
Standard painting		DAIKIN white (Munsell code 5Y7.5/1)	

(Note 1) • It is preset to be Max. discharge flow rate when delivered. (Max. discharge flow rate is theory value but not guarantee value.

• Refer to P29-30 b) about initial value of set up mode when delivered. as for other specifications, confirm delivery specifications (model figure).

• Although Max. pressure and Max. flow rate can be set up beyond the above adjustment range, be sure to observe above mentioned pressure range and flow.

• This hydraulic unit incorporates a safety valve, which has been set to work at value described below.

SUT00D4016 17.7MPa (maximum operating pressure + 2.0 MPa)

SUT00D6021 21.6MPa (maximum operating pressure + 1.0 MPa)

• However, in case of restraining surge pressure in the actuator operating as much as possible, adjust in accordance with P40 “Attached document : Points for high pressure safety valve adjustment.

(Note 2) • Even if it is with in the tolerance, when it changes on the + side, be careful because it may become regenerative over-load (Alarm stop) in answer by the main machine operating condition and load condition.

Working condition

Hydraulic oil (Note3)	Petroleum series of specific hydraulic oil/anti-wear hydraulic oil (Refer to our [General Hydraulic Catalog (HK196/TP)] to see the recommended brands.) • Viscosity grade : ISO VG 32 ~ 68 • Viscosity range : 15 ~ 400 mm ² /s • Contamination level : within NAS class 9
Tank oil temperature	0 ~ 60 (recommended working temperature range : 15 ~ 50) (Note 4)
Room temperature	0 ~ 35
Humidity	Below 85 %RH
Installation place	Indoor (must be fixed by screws)
Others	• Be sure to install no-fuse-breaker and short circuit breaker. • The electric wire connecting is wired to satisfy an European standard EN60204-1. • Ground (earth) terminal must be down to ground. • Do not turn ON/OFF the power frequently, it may cause remarkable short life of the controller. Use the stop control function, in case of using operation/stop in the frequency.


(Note 3) Do not use any hydraulic fluid other than mineral type (hydrous or synthetic) hydraulic oil (like water-glycol).

(Note 4) In case of using except recommended working temperature range, it may cause large pulsatory motion of pressure or reduce discharge flow, but it is not abnormal.


【5.Attention point in use】

- (1) To get the saving-energy features effectively, “Super unit” has solenoid valve to divide and connect the flow of double pump.
In case that the operation point of the machine is near to the switching point of this solenoid valve, performance would be unstable. In this case, flow or pressure rates need to be adjusted. Moreover, so the system sets Hysterisis rate to avoid unstable situation, flow or pressure also need to be adjusted in case the operating point is near to the rate.
- (2) The “Super unit” is installed to the motor pump with vibration absorbing rubber so that the vibration of the motor pump may not be effected to the unit. Since the discharge piping port is mounted free, be sure to pipe not to hit the cover even if the discharge pipe shakes with the anti-power such as the hose. As the piping to the unit, it is better to use hose connection.
- (3) The “Super unit” is equipped a AC fan motor to cool off the operation oil and the motor. Do not put an obstacle within 10cm from inhalation and exhaust side of the AC fan motor because of its ventilation.
- (4) The “Super unit” builds in the check valve with orifice on the discharge line. In case quick response is required to the pressure relief of the machine, the pressure relief circuit is necessary to provide separately. In addition to it, it is not trouble though oil flow noise is sometimes occurred from this orifice at stopping in case of large load volume.
- (5) The “Super unit” is adopted IPM motor, and reverse electric power occurs at the time of the diverting operation (regenerative operation). When switching of the high frequency on the operation condition that it is easy to cause reverse electric power becomes regenerative over-load, and then it may cause the unit stop.
- (6) The “Super unit” equipped with relief valve. Though this relief valve is set up the regular pressure when delivered, the long repetition operation of the equipment and contaminant in the hydraulic oil may decrease the setup pressure of the high pressure relief valve.
In this case, re-adjust the setup pressure of the high pressure relief valve according to that valve setup value (another document).
In order to suppress surge pressure to protect the master machine peripheral equipment (actuator, pressure gauge, etc.), it is recommended that the pressure setting should be set lower than safety valve setting 2.0Mpa for SUT00D4016, and 1.0 MPa for SUT00D6021.

【6.Parts】




Unit from the top view (without the full cover)



Unit from the front side (without the full cover)

【7. Hydraulic circuit】

Hydraulic circuit



▲ Caution : Above circuit diagram is SUT00D6021.
 Inverter motor drive pump for SUT00D4016 is attached no fan.

Parts

Part No.	Name
1-1	Inverter driving pump
1-2	Controller
1-3	Noise filter box and etc...
2	AC fan
3	Base


Piping

Since this hydraulic unit provided with 1 drain port and 1 unloading port and 1 discharge port and 1 suction port as well, piping according to the equipment.

Each piping port has taper plug (vinyl cap) when delivered.

Tighten the pipe with seal tape.

Outfit suction port pipe with filter.



▲ Caution

- This hydraulic unit has a check valve built in. In case of installing an inline check valve on discharge port separately, resonance occurs and it may give bad influence to the main machine, so do not use an inline check valve.
- Make sure that the suction pressure is -16.7 kPa or less. If the suction pressure exceeds -16.7 kPa, the hydraulic unit may generate large noise.

【8.Points for transporting, moving and installing】



- Though the vibration absorbed rubber is attached to the leg of the motor pump because of the low vibration, the low noise. It is fixed with a wing bolt (M8 × L15) as a transport vibration countermeasure when delivered.

Operation

- Before operation, remove the wing bolt (M8 × L15). If it is operated without removing the bolt, it may cause large vibration and noise.

Transporting

- When it is being transported, install the motor base on the base tank with the wing bolt (M8 × L15) surely, and fix it securely to protect the vibration absorbing rubber.
- When transporting, suspend for eyebolt(4 of M8).



▲ Danger

- In case that it is suspended except for eyebolt(pump piping), it is dangerous to fall and turnover.
- Confirm the weight of the hydraulic unit, and suspend it within the rated load of the hanger-hook.

▲ Warning

- When transporting, make sure to suspend equally with four position of the eyebolt.
- Never approach during transport by hanger hook. It is dangerous to be injured due to fall and turnover.

▲ Caution

- During transportation, be sure to fix it so that it may not be moved by vibration and another force.


Weight (without including hydraulic oil) : without noise filter

Type	SUT00D4016	SUT00D6021
Weight	61kg	66kg

Points for installation

Securing of ventilation

Do not put the obstacle that disturbs inhalation/exhaust of the AC fan within 10cm from the end of the unit. Moreover, install it in the good ventilation so that the unit may not be filled with heat, and be careful that temperature of inhalation becomes fixed surrounding temperature (less than 35).



▲ Warning

- When it is used in where there is no space of inhalation/exhaust, and heat place, the heat exchange function of the AC fan declines, and finally, oil temperature and temperature of the hydraulic equipment becomes unusual high temperature.
- In case of touching high temperature part, you may be burnt.

▲ Caution

- When it is used in where there is no space of inhalation/exhaust, and heat place, the motor and the controller become high temperature, and the life of the machine will be shortened apparently.
- When the motor and the controller become high temperature, temperature protection suspends its operation. (In case the motor and the controller become unusual high temperature, warning signal and alarm signal are outputted.)
- If using under high temperature condition continuously, it causes troubles and shorten the life of the hydraulic equipment such as the pump and the valve as well as the above electric parts.
- If using under high temperature condition continuously, it makes the quality of the hydraulic oil lower, and it's life becomes short.

Installation on horizontal place



- Install the hydraulic unit on the horizontal table or the horizontal floor.
- Fix the hydraulic unit not to move.
- As for method of installation and position, confirm delivery specifications (model figure).

▲ Warning

- If the hydraulic unit is not fixed with bolt, it is dangerous because of falling down and moving around by the hydraulic reverse-force in the pipes, so the unit must be fixed.

【9. Preparation for operation】

Electric wiring



▲ Caution

- In order to protect the electric circuit against short-circuiting and over-current and prevent electric shocks, the hydraulic unit main power supply must be equipped with a safety device (no-fuse breaker, earth leakage breaker, etc.) conforming to European Norm EN60947-2.
(For capacity of each model, see the table below.)
- Use a power supply connection device with 3-phase contact distance of at least 3 mm in the switch-OFF status.
- For connection of the ground terminal, ensure at least **Class 3 grounding condition**.
(Connect the ground terminal directly without using a breaker.)
- Be sure to complete installation of the hydraulic unit before wiring.
- Before wiring work, be sure to turn OFF the main power supply breaker, and make sure that the power is interrupted.
- Be sure not to connect the power supply cable to the I/O signal terminals.
- Do not apply an excessive power supply voltage higher than the specified power supply voltage to the hydraulic unit.
- No thermal relay is required. However, if a thermal relay is used, the hydraulic unit may malfunction due to influence of inverter switching.

▲ Caution

- Since this hydraulic unit has protect-over current function built in, thermal for protect-over current function is not necessary.


[Rated current and breaker setup value]

Unit type	Power source voltage and frequency						Beaker setup value			
	3	200V	50Hz	3	200V	60Hz		3	220V	60Hz
SUT00D4016		19.2A			19.2A			17.8A		30A
SUT00D6021		24.2A			24.2A			22.2A		50A

Carry out electric wiring after removing the cover of the noise filter box.
 (The cover is removed by loosening cross recessed truss screw(M4) of the figure below.)

The wiring of the main power source

- (1) Wire the electric cable through the wiring port of the controller.
 Use conduit or the cable clamp to be suitable for the wiring port that satisfies protection grade over IP54. (Wiring port: 28)
 Connect the earth line to the earth terminal of the controller.
 Connect power source line to appropriate terminal of the power source . (tightening torque: 1.0 N· m)
- (2)Set the cover of noise filter box as it set after wiring.
 (M4 cross recessed truss screw (tightening torque: 1.0 N· m)
 [recommended crimp-type terminal : TMEV-5.5-5]



Terminal stand for power source connection
 Wiring port
 <Removing the cover of noise filter box>

▲ Danger

- Use alternating current (AC) which is suitable for the power source specifications of the product.
- Use the electric wire which is suitable for its capacity. (Refer to the below table.)
- Do not connect the power source wire to earth connection point(L1,L2,L3).
- The earth connection point is connected with the motor frame, and ground the earth over D class ground (the third class ground).
- Be careful not to damage the conductor when stripping electric wire.
- Be careful not to stick out the conductor of wiring from the terminal stand.

▲ Caution

- Use the exclusive press terminal for the tip of the wire.
- The wire to insert into the cable clamp is to use multiple core cables like the following recommended electric wire. In case two and more electric wire is inserted, there is a gap between the electric wire and the cable clamp, and protection grade unable to be satisfied.

<power line>

Unit type	Wire size	Recommended electric wire	Recommended exclusive press terminal	Recommended cable clamp
SUT00D4016	Over 2.5mm ² (Over AWG14)	CE362 2.5mm ² x 4core (Kuramo made)	TMEV-2-5 (Nichifu made)	OA-W2216 (Ohm electrics made)
SUT00D60L21	Over 5.5mm ² (Over AWG10)	CE362 6.0mm ² x 4core (Kuramo made)	TMEV-5.5-5 (Nichifu made)	OA-W2219 (Ohm electrics made)


<signal line>

Unit type	Wire size	Recommended electric wire	Recommended cable clamp
SUT00D4016	0.5 ~ 0.3mm ² (AWG20 ~ 22)	KCV-36SB 0.3mm ² (Kuramo made)	OA-W-1611(Ohm electrics made)
SUT00D6021			Adaptation electric wire outside dimension: 9 ~ 11

Wiring of input and output signal lines


- (1) Wire the electric cable through the wiring port of the noise filter box. Use the cable clamp to be suitable for the wiring port. (Wiring port: hole 21)
- (2) Confirm connection diagram on the noise filter box cover, and then connect to input and output signal connection table of basic board.
- (3) After wiring, make sure to install and set the noise filter box cover as it was.

[COM - ALMa]	Normal: closed	Abnormal: opened
[COM - ALMb]	Normal: opened	Abnormal: closed



Input/output signal wiring diagram

(Note.1)
This terminal stand cannot be used.



Terminal stand for alarm/control signal

《The cover of the distribution box has been removed》

▲ Danger

- Use the electric wire, cab-tire cable with shield which is suitable for AWG22 (0.3sq).
- Be sure to treat the end of shield cable properly, and ground the one side.
- Do not connect the alarm connect line to the terminal stand for power source.
- Be careful not to damage the conductor when stripping electric wire.
- Be careful not to stick out the conductor of wiring from the terminal stand.


▲ Caution

- As for alarm output signal connect “ALMa” and “COM” of wiring diagram at normal operation.
- In case of preventing end of the wire from separating, treat its end with solder or use the below mentioned crimping terminal with insulation sleeve. (Refer to maker’s catalogue “WAGO made” for handling them.)

For AWG22 0.3 sq: 216-322 light green

For AWG20 0.5 sq: 216-221 white

Press tool: 206-204 Bio- crimp



The method of wiring to the terminal stand

Loosen the screw with the driver.

Make sure of stripped wire length, and insert them until the end without separating.

Tighten the screw with the driver

Make sure of wiring by pulling the electric wire slightly

Stripped wire length: 6mm



Input and output signal specification

Controller of this unit equipped with input/output signal terminal to contact interface from the outside.

Refer to the following pages about details of each signal wire specifications.

Diagram symbol.	Type	Terminal function	Remarks
COM2	Digital input terminal.	Common digital input	Able to control operation of this unit from the outside. Input 0: input START/STOP control Input 1 and 2: PQ choice, 0-3 switching by combination.
DIN0		Digital input 0	
DIN1		Digital input 1	
DIN2		Digital input 2	
DOUT0	Digital connection output terminal.	Digital output 0	Able to output status of this unit. Refer to alarm code on page 40.
DOUT1		Digital output 1	
COM1		Common digital output	Output 0: Warning Output 1: Pressure switch (In case "P18" alarm output mixed setup is "0")
ALMa		Connection output a	Output alarm status of this unit. (In case "P18" alarm output mixed setup is "0") Refer to alarm code on page 40.
ALMb		Connection output b	
COM		Common connection output	

Digital input.


Sequencer input signal to control this unit from the outside. Connect as following point as required.

Diagram symbol	Signal	Remarks
COM2	Common digital input	Minus common (In case of using as plus common, refer to [attached document: common for the input signal of the outer I/O signal] of P47.)
DIN0	Digital input 0	Control START/STOP. Able to switch input signal operation by switching START/STOP signal while setup mode (setup mode: P11). (Refer page 25)
DIN1	Digital input 1	Able to switch PQ choosing 0-3, as combination of attached list. (Refer page 25, about setup of PQ choosing.)
DIN2	Digital input 2	

Notes) While stopping, it indicates “STP” on the panel by digital input.

Combination of PQ choosing digital input

PQ choice NO.	Digital input 1	Digital input 2
0	OFF	OFF
1	ON	OFF
2	OFF	ON
3	ON	ON




▲ Caution
<ul style="list-style-type: none"> • Use more than DC24V ± 1V/0.5A for external power source. • It is impossible to supply power source from this controller to the exterior. • Electric current for each input circuit is 5mA(Typ.) <p>Mind the minimum current around contact, in case of constructing circuit around contact.</p>

Digital output / contact output


Digital output signal of which output the state of this unit. Connect as following point as required. Refer to alarm code (page 33) about output contents.

Diagram symbol.	Signal	Remarks
DOUT0	Digital output 0	Warning
DOUT1	Digital output 1	Pressure switch
COM1	Common digital output	Minus common



▲ Caution	
<ul style="list-style-type: none"> • Use more than DC24V ± 1V/0.5A for exterior. It is impossible to supply power source from this controller to the exterior. • Output circuit of this controller is minus common. • Maximum output current of output circuit is 30mA(load resistance) for a circuit. In case of operating loading current more than permissible level, may damage the circuit. • In case of operating inductive load, enforce surge prevention measure. 	

Diagram symbol	Signal	Remarks
ALMa	Contact output a	Alarm a
ALMb	Contact output b	Alarm b
COM	Common contact output	Common



▲ Caution	
<ul style="list-style-type: none"> • Switching capacity of contact output is DC30V/0.5A(load resistance). In case of operating loading current more than permissible level, may damage the contact point. • However, minimum applied load of connection output is DC10mV/10 μ A, it is minimum tentative value that open/close possible for minute loading. • In case of operating inductive load, enforce surge prevention measure. 	


【10.Test run】

Hydraulic circuit


After completing pouring fixed amount of hydraulic oil into tank, piping, and wiring, perform test run.

(Before power on, make sure to reconfirm wiring of earth or power source cables properly.)


Starting confirmation



Flushing operation



Changing oil



Removing air

- Turn the switch of machine controller “ON”.
 Confirm the pump rotation sound, pressure rising by the indication panel.
 Confirm AC fan motor rotation of oil-cooler.

Note) It takes about 3 seconds that starting this hydraulic unit after power on.
 (Rising pressure time depends on oil volume in the pipe.)
 It may take time to raise pressure more than setup pressure switch and output pressure switch signal by piping lengthen (oil volume in the pipe).
 In this case, setup main machine not to receive alarm output.





- After confirmation of the start, perform flushing operation about 2hours with flowing the oil in circuit pressure at 1-1.5 MPa (low pressure). As flushing operation, connect all piping with loop style except the actuator, and operate through the return filter.
- While flushing operation, confirm piping properly at each part, or oil leakage.
- After completing the flushing operation, first confirm filter, if it clogged, replace filter element, then, remove hydraulic oil in the tank completely out of drain plug.
- Pour fresh hydraulic oil.
 (Within NAS 9 class pure oil is used as fresh hydraulic oil.)
- Remove the air of hydraulic circuit completely.
 If the air has not been removed thoroughly,
 abnormal operation of actuator, such as cylinder
 abnormal noise in the pump or in the valve
 may occur.


▲ Danger
• In the process of air removing, be careful because there is a case of high pressure or high temperature oil spouts.

【11. Operation manual of the control panel】

It is easy for this hydraulic unit to monitor, setup, and adjust such as pressure/flow by operation of controller key switch.

General description

The control panel is composed of 3 digits LED **88.8**, mode key , setting key  , and ENT (enter) key , it normally indicates the actual pressure, and possible to change each mode as monitor indication and setting indication by key switching.




Explanation of each mode

- Normal mode: indicate actual pressure and alarm code
- Monitor mode: indicate pressure switch setup value, pressure setup value for each, flow setup value for each, actual flow, actual revolution speed.
- Setting mode: practice set up/change of pressure or flow.
- Alarm mode: It is possible to confirm alarm occurrence record.

Shift to each mode

The key switch operation of shift to each mode is as following figure.



Operation manual of each mode

a) Monitor mode

While monitor mode, it is possible to monitor item on the table below by choice.

Item	Content	
n00	Pressure switch setup value	(MPa) [in case of choosing PSI unit × 10PSI unit] Indicate pressure switch setup value.
n01 Note) 1	Pressure setup value	(MPa) [in case of choosing PSI unit × 10PSI unit] Indicate pressure setup value of present PQ choosing number high and low pressure alternatively.
n02	Discharge volume setup value	(L/min) Indicate discharge volume setup value of present PQ choosing number small and large discharge flow alternatively.
n03	Discharge volume	(L/min) Indicate present discharge volume.
n04 ^{note)2}	The latest alarm code	Indicate the code of the latest occurred alarm.
n05	Revolution	(× 10 min ⁻¹) Indicate present revolution.
n06	Operation mode indication	Indicate present switching mode (joining/dividing flow) of solenoid operated valve operation mode, and present PQ choosing number.
n07	Reverse revolution of stopping power supply	Indicate reverse revolution caused by motor reverse of loading, in case of stopping the unit power supply. It is be used for load volume estimate of machine.
n08	Regenerative load integration rate indication	Indicate load integration rate of present regenerative breaking resistance.


Note) 1

As for the setup in factory, standard is MPa indication. Make sure to treat such as indication sticker to identify PSI setup, in case of changing PSI mode.

If using the machine without any indication sticker in Japan, would be punished by the measuring law. Please arrange indication sticker in your company.

Note) 2

Refer to the alarm indication item, for the contents of alarm code.

It is possible to confirm actual number of power on by pushing  key while alarm code indicating.

Refer to the operation example as below.

<Example> Monitoring actual discharge volume.

Operation	Key operation	3 digit LED	Remarks
<ul style="list-style-type: none"> • Power on (Start/Operation) • Actual pressure indication <li style="text-align: center;">↓ • Shift to monitor mode <li style="text-align: center;">↓ • Choosing item number <li style="text-align: center;">↓ • Monitor indication <li style="text-align: center;">↓ • Return to actual pressure indication 	<ul style="list-style-type: none"> <li style="text-align: center;">⊖ <li style="text-align: center;">⤴ <li style="text-align: center;">⤵ <li style="text-align: center;">⊖ 	<ul style="list-style-type: none"> <li style="text-align: center;">15.7 <li style="text-align: center;">\ \ / / <li style="text-align: center;">/ / \ \ <li style="text-align: center;">n 0 0 <li style="text-align: center;">n 0 3 <li style="text-align: center;">4 1.0 <li style="text-align: center;">15.7 	<ul style="list-style-type: none"> <li style="text-align: center;">⤴ Push 3 times flash 41.0 L/min Discharge volume (theoretical value)

To monitor other item, choose the monitor item after returning the actual pressure indication.

b) Setting mode

While setting mode, it is possible to setup or change of pressure/flow by operation panel.

While setting mode, item (content) or adjustment range of setup/change, refer to the table on page29-30.

Concerning initial setting-value or adjustment range of non-standard or special required type product, refer to the independent delivery specifications.

Note:

Above mentioned setup value of discharge volume is theoretical value (multiply of theoretical displacement and revolution), may differs slightly to the actual discharge volume.

While P00-P03 pressure/flow setup, it is impossible to setup as follows.

- a) When setting up { PH* } less than { PL* } setup value, it comes to { PL* = PH* } automatically.
- b) It is impossible to setup for { PL* } more than { PH* } setup value.
- c) When setting up { qL* } less than { qH* } setup value, it comes to { qH* = qL* } automatically.
- d) It is impossible to setup for { qH* } more than { qL* } setup value.

{ PH* } means pressure setup value of high pressure,

{ qH* } means setup value of low flow,

{ PL* } means pressure setup value of low pressure,

{ qL* } means setup value of high flow.

example) In case of setup as { PL0 } = 6.0MPa, and change to setup as { PH0 } = 5.5MPa would change to { PL0 } = 5.5MPa automatically.



















While setting mode, it is possible to setup (adjust) item on the table below by choice.

No	Title	Content
P00	PQ choice setup for 0 pressure/flow	Mode for setup pressure/flow of each PQ choice No Items are setup as follows: P H 《high pressure (single) pressure setup》 q H 《high pressure (single) flow volume setup》 P L 《low pressure (join) pressure setup》 q L 《low pressure (join) flow volume setup》
P01	PQ choice setup for 1 pressure/flow	
P02	PQ choice setup for 2 pressure/flow	
P03	PQ choice setup for 3 pressure/flow	
P04	Intensified pressure rate setup value at PQ choice change	Setup intensified pressure time (unit: second/MPa), in case of intensifying setup pressure after PQ choice change.
P05	Reduced pressure rate setup value at PQ choice change	Setup reduced pressure time (unit: second/MPa), in case of reducing setup pressure after PQ choice change.
P06	Increased speed rate setup value at PQ choice change	Setup increasing time (unit: second/1000min ⁻¹), in case of increasing setup flow after PQ choice change.
P07	Decreased speed rate setup value at PQ choice change	Setup decreasing time (unit: second/1000min ⁻¹), ¹ in case of decreasing setup flow after PQ choice change
P08	Setup of maintenance for pressure switch indication	Setup of function by indicating the action of pressure switch. Details about function refer to “alarm code and classification at sight” on page 33.
P09	Setup of switching pressure unit	Switch unit of normal pressure indication “ MPa ”to “ × 10PSI ”.
P10	Output permission of thermistor related	Setup output function of motor and controller alarm for temperature.
P11	Switching start/stop signal	Setup start/stop operation, while signal input.
P12	Pressure switch setup	Setup pressure switch effective/ineffective or operation pressure.
P13	Setup of pressure alarm delayed output time	Setup the time delay between pressure of pressure switch decreased to the operation pressure and output.
P14	Response gain	Adjust control response value. (Reply becomes as fast as this value is small.)
P15	Command rate of regenerated load	Adjust regenerated load, in case of growing regenerated load by normal pressure response (FF DH).
P16	Reply time setup of high and low switching	Adjust minimum time for switching solenoid-operated valve, in case of operation point located around high pressure low pressure (solenoid-operated valve diverting) diverting point and unstable.
P17	Non-sensitive zone setup of revolution single diverting	Adjust non-sensitive zone of actual diverting revolution, in case of operation point located around high pressure low pressure (solenoid-operated valve diverting) diverting point and unstable.
P18	Alarm output mixed setup	It sets up contact point output (alarm, warning and pressure switch) whether outputs independently or unity as one point. (Refer to the time chart of the attached document of P41.)

Concerning the setup of P14 to P17, generally no need to change setup, in case of special circuit occasion such as extra load volume, need to change setup.

As for the type that does not indicate P18, contact point output independently as equal with setup value “0”.

- Changing process of flow setup
Operation examples are as follows.
- < example > PQ choosing 1: low pressure flow 41L/min change into that of 32.8L/min.

Operation	Key operation	3 digit LED	Remarks
<ul style="list-style-type: none"> • Power supply on 		15.7	
<ul style="list-style-type: none"> • Actual pressure indication • Setting mode 	 Push two keys simultaneously for more than 2 seconds.		2 seconds later
<ul style="list-style-type: none"> • Choosing item No. 	 or 		Choosing PQ 1
<ul style="list-style-type: none"> • Setup value indication 		 ↓ ↑ 	Indicate pressure setup value of high pressure for choosing PQ 1
<ul style="list-style-type: none"> • Choosing PQ item 	 push (←)3 times Indicate in the order of →PH1→qH1→PL1→ qL1→	 ↓ ↑ 	Indicate pressure setup value of low pressure for choosing PQ 1
<ul style="list-style-type: none"> • Changing setup value 			
<ul style="list-style-type: none"> • Setup value entry 		 ↓ ↑ 	
<ul style="list-style-type: none"> • Return to actual pressure indication 			

Note:










Setup value of flow shown by interval of [theoretical displacement × 100min⁻¹], so that it cannot be the integer. And also indicating the number of rounded off to one decimal place after the calculation as flow.

	Theoretical displacement (cc/rev)	
	Pump capacity in low pressure	Pump capacity in high pressure
SUT00D4016	9.13	3.56
SUT00D6021	14.55	5.05

• Changing process of pressure setup

Operation examples are as follows

< example > PQ choosing 1: pressure of low pressure 6.9MPa change into that of 6.0MPa.

Operation	Key operation	3 digit LED	Remarks
<ul style="list-style-type: none"> • Power supply on <li style="text-align: center;">↓ • Actual pressure indication • Setting mode 		15.7	
<ul style="list-style-type: none"> <li style="text-align: center;">↓ 	 Push two keys simultaneously for more than 2 seconds.	P00 / / / \	2 seconds later
<ul style="list-style-type: none"> <li style="text-align: center;">↓ • Choosing item No. 	 or 	P0.1	Choosing PQ 1
<ul style="list-style-type: none"> <li style="text-align: center;">↓ • Setup value indication 		PH1 / / / \	Indicate pressure setup value of high pressure for choosing PQ 1
<ul style="list-style-type: none"> <li style="text-align: center;">↓ • Choosing PQ item 	 push () 2 times Indicate in the order of PH1 qH1 PL1 qL1	PL1 6.9	Indicate pressure setup value of low pressure for choosing PQ 1
<ul style="list-style-type: none"> <li style="text-align: center;">↓ • Changing setup value 	 or 	6.0	
<ul style="list-style-type: none"> <li style="text-align: center;">↓ • Setup value entry 		PL1	
<ul style="list-style-type: none"> <li style="text-align: center;">↓ 		6.0	
<ul style="list-style-type: none"> <li style="text-align: center;">↓ • Return to actual pressure indication 		15.7	

(SUT00D4016 Setup range)

Item No.	Contents	Initial value	Usable range ^{note1}	Indication unit
P00	Setup of pressure/flow for PQ choosing 0			
	PH0: high pressure (single) pressure setup ^{note2}	3.5	1.5~15.7	(MPa)
		50	22~227	(×10 PSI)
	qH0: high pressure (single) flow setup ^{note3}	14.2	2.1~16.0	(L/min)
		PL0: low pressure (join) pressure setup ^{note2}	3.5	1.5~6.9
50	22~100		(×10 PSI)	
P01	Setup of pressure/flow for PQ choosing 1			
	PH1: high pressure (single) pressure setup ^{note2}	3.5	1.5~15.7	(MPa)
		50	22~227	(×10 PSI)
	qH1: high pressure (single) flow setup ^{note3}	14.2	2.1~16.0	(L/min)
		PL1: low pressure (join) pressure setup ^{note2}	3.5	1.5~6.9
50	22~100		(×10 PSI)	
P02	Setup of pressure/flow for PQ choosing 2			
	PH2: high pressure (single) pressure setup ^{note2}	3.5	1.5~15.7	(MPa)
		50	22~227	(×10 PSI)
	qH2: high pressure (single) flow setup ^{note3}	14.2	2.1~16.0	(L/min)
		PL2: low pressure (join) pressure setup ^{note2}	3.5	1.5~6.9
50	22~100		(×10 PSI)	
P03	Setup of pressure/flow for PQ choosing 3			
	PH3: high pressure (single) pressure setup ^{note2}	3.5	1.5~15.7	(MPa)
		50	22~227	(×10 PSI)
	qH3: high pressure (single) flow setup ^{note3}	14.2	2.1~16.0	(L/min)
		PL3: low pressure (join) pressure setup ^{note2}	3.5	1.5~6.9
50	22~100		(×10 PSI)	
P04	Intensified pressure rate setup value at PQ choice change	0.1	0.01~1.00	(sec/MPa)
P05	Reduced pressure rate setup value at PQ choice change	0.1	0.01~1.00	(sec/MPa)
P06	Increased speed rate setup value at PQ choice change	0.1	0.01~1.00	(sec/×1000min ⁻¹)
P07	Decreased speed rate setup value at PQ choice change	0.1	0.01~1.00	(sec/×1000min ⁻¹)
P08	Setup of hold for pressure switch indication	0	0:NO function 1:Indication hold of operation 2:Indication and memory of operation	—
P09	Setup of switching pressure unit	0	0: MPa indication 1: PSI indication	—
P10	Output permission of thermister related	1	0: No indication of operation 1: Indication hold of operation	—
P11	Switching start/stop signal	1	0: Input 0, start operation 1: Input 1, stop operation	—
P12	Pressure switch setup	0	0~35.0(0: No function)	(MPa)
			0~507(0: No function)	[in case of choosing PSI unit × 10PSI unit]
P13	Setup of pressure alarm delayed output time	0	0.00~9.99 (Max. 9.99seconds)	(sec)
P14	Response gain ^{note4}	30	10~999 (It becomes as fast response as this value is small)	—
P15	Command rate of regenerative load	50	30~100	(%)
P16	Response time setup of high and low switching	0.20	0.05~1.00	(sec)
P17	Non-sensitive zone setup of revolution single switching	400	0~999	(min ⁻¹)
P18	Alarm output mixed setup	0	0: independent alarm output 1: unity alarm output Refer to attached document. ^{Note4}	-

(SUT00D6021 Setup range)

Item No.	Contents	Initial value	Usable range ^{note1}	Indication unit
P00	Setup of pressure/flow for PQ choosing 0			
	PH0: high pressure (single) pressure setup ^{note2}	3.5	1.5~20.6	(MPa)
		50	22~298	(× 10 PSI)
	qH0: high pressure (single) flow setup ^{note3}	20.2	3.0~22.7	(L/min)
	PL0: low pressure (join) pressure setup ^{note2}	3.5	1.5~6.9	(MPa)
50		22~100	(× 10 PSI)	
qL0: low pressure (join) flow setup ^{note3}	61.1	8.7~61.1	(L/min)	
P01	Setup of pressure/flow for PQ choosing 1			
	PH1: high pressure (single) pressure setup ^{note2}	3.5	1.5~20.6	(MPa)
		50	22~298	(× 10 PSI)
	qH1: high pressure (single) flow setup ^{note3}	20.2	3.0~22.7	(L/min)
	PL1: low pressure (join) pressure setup ^{note2}	3.5	1.5~6.9	(MPa)
50		22~100	(× 10 PSI)	
qL1: low pressure (join) flow setup ^{note3}	61.1	8.7~61.1	(L/min)	
P02	Setup of pressure/flow for PQ choosing 2			
	PH2: high pressure (single) pressure setup ^{note2}	3.5	1.5~20.6	(MPa)
		50	22~298	(× 10 PSI)
	qH2: high pressure (single) flow setup ^{note3}	20.2	3.0~22.7	(L/min)
	PL2: low pressure (join) pressure setup ^{note2}	3.5	1.5~6.9	(MPa)
50		22~100	(× 10 PSI)	
qL2: low pressure (join) flow setup ^{note3}	61.1	8.7~61.1	(L/min)	
P03	Setup of pressure/flow for PQ choosing 3			
	PH3: high pressure (single) pressure setup ^{note2}	3.5	1.5~20.6	(MPa)
		50	22~298	(× 10 PSI)
	qH3: high pressure (single) flow setup ^{note3}	20.2	3.0~22.7	(L/min)
	PL3: low pressure (join) pressure setup ^{note2}	3.5	1.5~6.9	(MPa)
50		22~100	(× 10 PSI)	
qL3: low pressure (join) flow setup ^{note3}	61.1	8.7~61.1	(L/min)	
P04	Intensified pressure rate setup value at PQ choice change	0.1	0.01~1.00	(sec/MPa)
P05	Reduced pressure rate setup value at PQ choice change	0.1	0.01~1.00	(sec/MPa)
P06	Increased speed rate setup value at PQ choice change	0.1	0.01~1.00	(sec/× 1000min ⁻¹)
P07	Decreased speed rate setup value at PQ choice change	0.1	0.01~1.00	(sec/× 1000min ⁻¹)
P08	Setup of hold for pressure switch indication	0	0: NO function 1: Indication hold of operation 2: Indication and memory of operation	—
P09	Setup of switching pressure unit	0	0: MPa indication 1: PSI indication	—
P10	Output permission of thermister related	1	0: No indication of operation 1: Indication hold of operation	—
P11	Switching start/stop signal	1	0: Input 0, start operation 1: Input 1, stop operation	—
P12	Pressure switch setup	0	0~35.0(0: No function)	(MPa)
			0~507(0: No function)	[in case of choosing PSI unit × 10PSI unit]
P13	Setup of pressure alarm delayed output time	0	0~999 (Max. 9.99seconds)	(sec)
P14	Response gain ^{note4}	30	10~999 (It becomes as fast response as this value is small)	—
P15	Command rate of regenerative load	50	30~100	(%)
P16	Response time setup of high and low switching	0.20	0.05~1.00	(sec)
P17	Non-sensitive zone setup of revolution single switching	400	0~999	(min ⁻¹)
P18	Alarm output mixed setup	0	0: independent alarm output 1: unity alarm output Refer to attached document. ^{note5}	-

- ^{note 1} Mind to use within the usable range, though setup/ adjustment with a control panel can be setup against usable range of above table.
- ^{note 2} Make sure that the pressure setting is lower than the below values.
SUT00D4016 the set value of relief valve - 2.0 MPa
SUT00D6021 the set value of relief valve - 1.0 MPa
- ^{note 3} In normal load volume, no needs to adjust a response gain.
In case of changing inappropriate gain, unstable phenomenon or surge pressure might occur.
- ^{note 4} Setup value of flow shown by interval of [theoretical displacement $\times 100\text{min}^{-1}$], so that it cannot be the integer. And also indicating the number of rounded off to one decimal place after the calculation as flow.
In case it cannot be set up the value as demand, setup the closest value as demand.
- ^{note 5} It sets up contact point output (alarm, warning and pressure switch) whether outputs independently or unity as one point. However, as for the type that does not indicate setup item, it is fixed as “0: independent alarm output”.











c) Alarm mode

While alarm mode, it is possible to confirm contents on the table below by choosing A00-A09.

Item No	Contents	Remarks
A00 - A09	Indication of alarm contents. (Refer to code attached table)	It becomes the latest alarm as small as the number.

Operation examples are as follows.

<Example> Confirm contents (E10 : IPM alarm) of an alarm (A01) before the latest one

Operation	Key operation	3 digit LED	Remarks
<ul style="list-style-type: none"> • Power supply on • Actual pressure indication • Alarm mode 	 Push 2keys simultaneously for more than 2 seconds.	  2 seconds later (Indicate the latest alarm)	2 seconds later.
<ul style="list-style-type: none"> • Choose record number 	Push  once.	 Indication of an alarm before the latest one.	
<ul style="list-style-type: none"> • Alarm content indication 		  	Indicate alarm contents and power supply No. by turns in every 1 second.
<ul style="list-style-type: none"> • Return to actual pressure indication 			

The indication list of alarm code

The unit equipped with alarm detective function, which classified as follows.

The panel indication, unit operation, and external output signal at abnormal occurrence

Classification	Detection timing	Output status	Indication status	Action
	Normal operation	Refer to the table as below.	Alarm No. indication	Operation stop
	Power supply on Initialization		Flash indication of alarm No. and abnormal setup No. by turns.	
	Normal operation		Flash indication of warning No. and actual pressure by turns.	Operation continuation
	Normal operation		Indication of warning No.	

The list of alarm code and classification.

(At independent alarm output : alarm output mixed set up[p18] is "0")

(At united alarm output : alarm output mixed set up[p18] is "1")


Classification	Alarm contents	Panel indication	Output status					
			At independent alarm output				At united alarm output	
			Relay output		Warning	Pressure switch	Relay output	
			Contact A	Contact B			Contact A	Contact B
	Power off		×		×	×		
	Power on : normal state	Actual indication		×			×	
	Output device abnormal	E10	×			×		
	Momentary excess electric current	E11	×			×		
	Over speed	E12	×			×		
	Regenerative brake over load	E14	×			×		
	Voltage shortage	E15	×			×		
	Over voltage	E16	×			×		
	Electron thermal	E17	×			×		
	Abnormal detection of magnetic pole	E18	×			×		
	Encoder break	E20	×			×		
	Motor wiring break	E21	×			×		
	Abnormality of pressure sensor system	E30	×			×		
	Abnormal motor start up	E31	×			×		
	Motor thermista break	E40	×			×		
	Abnormal motor temperature rise	E41	×			×		
	Heat radiation fin thermista break	E42	×			×		
	Abnormal fin temperature rise	E43	×			×		
	CPU out of control (watch dog)	E91	×		×	×		
	Abnormal EEPROM data (1)	E93	×			×	×	
	Abnormal EEPROM data (2)	E94	×			×	×	
	Abnormal motor temperature warning	L44	×		×	×		
	Abnormal fin temperature warning	L45	×		×	×		
	Pressure decrease	L62		×	×	×	×	
	Pressure switch operation <small>note1</small>	L63		×		×	×	

When the alarm of classification occurs, it keeps indicating alarm code after recording the alarm.

When the alarm of classification ① occurs, the pressure switch does not work. It keeps the condition just before Alarm occurrence.

When alarm output mixed set up[p18] is "1" (At united alarm output), even if warning or pressure switch works, alarm signal is outputted.

note 1 Item No. 5: pressure switch operation (L63) alarm code is indicated, while in setup mode "P08" indication hold setup of pressure switch setup "1" or "2", and "P12"pressure switch setup is completed.

Indication hold would not be canceled until press  key, while pressure switch indication maintenance setup is "1" or "2".

In case of setup mode "P08" indication hold setup of pressure switch setup "2", and "P12"pressure switch setup less than which pressure, memorized in alarm record.

※As for time chart, refer to 【Attached document : Power on and the time chart of the alarm】

【12. Maintenance】

To maintain motor pump performance for long term and fine, operate periodical maintenance about following item, and if there is problem, perform repair or replacement.

An inspection time, period is shown as a standard on following table, it varies drastically depends on the use condition, environment, and so on.

Periodic inspection

Object/ item	Inspection time/period	Inspection principles
Oil		
• Confirmation of oil amount	daily • as required	Confirm float locates between red line and yellow line of oil gauge. Confirm hydraulic oil becoming muddy and bubble getting mixed.
• Confirmation of oil temperature	daily • as required	Confirm that it is less than 60 ° . (Normally, make sure to usable range among 15 -50 .
• Confirmation of oil color	Once/6 months	It is possible to confirm deterioration of oil-hydraulic oil by color. If recognize oil color changing to dark-brown (ASTM level 4 : bright-yellow) , change hydraulic oil
AC fan Fan motor rotation	daily • as required	Confirm fan motor rotation.
Pressure indication Operation confirmation Indicated pressure confirmation	daily • as required daily • as required	Confirm the indication change as change of loading condition. Confirm pressure indication value of DH as it setup.
Noise/ vibration	daily • as required	Confirm no abnormal noise or vibration.
Electric wiring	Once/ 6 months	Confirm no crack and damage in covering material of wire. Measure insulation resistance, and confirm no decline of the insulation resistance Confirm to ground the earth properly.
Hose	Once/ a year	Confirm no crack, damage and flaw.
Screw/ piping	daily • as required	Confirm whether there is loosen part of screws or piping, oil leakage.

Cleaning and change

Object/item	Operation time/period	Operation principles
Oil changing	Once/ a year	Change hydraulic oil periodically. Long time use of this hydraulic unit without changing oil may be harmful for operation and life of the hydraulic equipment.
AC fan cleaning	Once/ a year	Disassemble and clean, as following maintenance principle on page 36-39.

▲ Danger

Do not touch rotary point.

When touching the inside of the controller, observe the process to prevent an electric shock.

-) Turn off the main power source of the hydraulic unit.
(Turn off the power source breaker of the circuit supplying a power.)
Put a bill such as “Operation prohibited (Working)” on the power source breaker, and prevent wrong operation.
-) After more than 5 minutes pass, remove the cover of the controller box.
Since large capacity condenser is used in the controller, if it operates under charging in the condenser there is fear of the electric shock. Be sure to leave more than 5 minutes (time to discharge electricity inside the condenser).

When starting operation, turn on electricity after installing all of the cover on the controller.

When touching the inside of the noise filter box, observe the process to prevent an electric shock.

-) Turn off the main power source of the hydraulic unit.
(Turn off the power source breaker of the circuit supplying a power.)
Put a bill such as “Operation prohibited (Working)” on the power source breaker, and prevent wrong operation.
-) After more than 5 minutes pass, remove the cover of the noise filter box.
Since large capacity condenser is used in the noise filter box, if it operates under charging in the condenser there is fear of the electric shock. Be sure to leave more than 5 minutes (time to discharge electricity inside the condenser).

When starting operation, turn on electricity after installing all of the cover on the noise filter box.

AC fan maintenance principals (SUT00D4016)

▲ Warning

- Stop main power source and operation, before starting maintenance.
 Wear protective glasses and gloves, while operation.
- Be careful not to get foreign substance into eye, while air-blow.

▲ Caution

- Be careful not to load strong power on power supply wire or connector of fan motor, while operation.

1 . Removing AC fan


Open the controller cover and remove fan connector.

Unfasten hose bands (2 points), and remove hoses (2) on the top of the oil cooler.

Note) Blind plug or other protection of oil leakage should be fit on hose because of protecting back flow when removing.


Loosen hexagon socket bolt (M5 × L12 : 2), and remove oil cooler.

- There is a bolt on the unit back side as well.



2. AC fan disassembling

- Loosen small cross recessed screw (M4xL70: 4), and divide AC fan bracket, fan motor and finger-guard.



3. AC fan bracket cleaning

Blowing AC fan bracket by air or steam, and clean dust or drain stick / pile up on the fin.

4. Fan motor cleanings

Clean not only fan body or casing parts, but also surroundings of fan and casing crevice with waste cloth.

▲ Caution
Do not steam/air blow. Do not steam/air blow, otherwise a foreign substance get in the inside of the motor.

5. Re-assembling

Re-assemble as it was, after cleaning completed.

Confirm operation driven properly, as following test run on page 21, after re-assembling completed.

Be careful to setup inhalation/exhaust direction of oil cooler (page 14).

AC fan maintenance principals (SUT00D6021)

▲ Warning
Stop main power source and operation, before starting maintenance. Wear protective glasses and gloves, while operation. • Be careful not to get foreign substance into eye, while air-blow.

▲ Caution
• Be careful not to load strong power on power supply wire or connector of fan motor, while operation.

1 . Removing AC fan


Open the controller cover and remove fan connector.

Unfasten hose bands (2 points), and remove hoses (2) on the top of the oil cooler.

Note) Blind plug or other protection of oil leakage should be fit on hose because of protecting back flow when removing.


Loosen hexagon socket bolt (M5 × L16 : 2), and remove oil cooler.

- There is a bolt on the unit back side as well.



2. AC fan disassembling

- Loosen small cross recessed screw (M4xL70: 2), and divide AC fan bracket, fan motor and finger-guard.



3. AC fan bracket cleaning

Blowing AC fan bracket by air or steam, and clean dust or drain stick / pile up on the fin.

4. Fan motor cleanings

Clean not only fan body or casing parts, but also surroundings of fan and casing crevice with waste cloth.

▲ Caution

Do not steam/air blow.

Do not steam/air blow, otherwise a foreign substance get in the inside of the motor.

5. Re-assembling

Re-assemble as it was, after cleaning completed.

Confirm operation driven properly, as following test run on page 21, after re-assembling completed.

Be careful to setup inhalation/exhaust direction of oil cooler (page 14).

【Attached document: Points for high pressure safety valve adjustment】

This hydraulic unit does not need to change the setup of the high pressure safety valve delicately, even if setup pressure is adjusted. This unit can realize stable performance as a result of improving the drive system of the motor drastically though the setup of the high pressure safety valve is not adjusted. However, in case of the following three cases, refer to the following “Points for high pressure safety valve adjustment”, and adjust the high pressure safety valve again.

1. In case of safety valve setup adjustment is necessary.

Even if it is used in max. pressure setup, the safety valve does not work by usual pressure control (except the transition when the actuator of the machine is circuit block situation by stopping) but, in case of such condition that the long repetition operation and contaminant of the hydraulic oil lower the setup pressure of the safety valve so that the safety valve works even in usual condition.

【How to judge it】

- In case oil temperature rises earlier than it was.
 - In case the number of rotation decreases under pressure hold condition as indication of the number of rotation, safety valve adjustment screw is turned to tighten direction.
2. In case of restraining the surge pressure which is greatly beyond the setup pressure in the relation such as pressure-resistant of the hose as much as possible.
3. When the pressure set value is changed from the factory setting:

In order to suppress surge pressure to protect the master machine peripheral equipment (actuator, pressure gauge, etc.), it is recommended that the safety valve set pressure should be set "pressure of the unit + 1.0 MPa"(SUT00D6021) or "pressure of the unit + 2.0 MPa"(SUT00D4016).

《Adjustment point of the safety valve》

Loosen the lock nut referring to the safety valve expansion figure of the bottom. (Lock nut is M10: width 14mm)
 In accordance with the standard figure of the length of pressure adjustment screw, adjust it to about the screw length which cope with the pressure as a control pressure.

*The tip of the adjustment screw : hexagon width 5mm

*Be careful because about 7.7 MPa changes per turn of the adjustment screw.

Power on the hydraulic unit, make the setup mode by the panel key operation, and adjust the pressure setup to the pressure as be settled. Choose [n05] (indication of the number of rotation) of the monitor mode by the panel key, and present number of rotation is indicated. Adjust the length of pressure adjustment screw in the front-back direction, and find the operation start point of the right figure.

Tighten the pressure adjustment screw from the operation start point to turn 1/8 for SUT00D6021 and 1/4 for SUT00D4016 clockwise.




Tighten the lock nut, and adjustment is finished.

(Be careful not to turn the adjustment screw when tightening the lock nut.)

Be careful to setup such as high pressure over 20MPa.

(In case of setting the safety valve setup too high, the pump may be damaged by the surge pressure.)


As for setup point, make the pressure adjustment screw turn clockwise once, and tighten it, perform the above after set up “to set up pressure-7.7MPa[equal to one turn of the adjustment screw]” by the above points (~).




【Attached document: Power on and alarm system time chart】

1. When the set up item P18 is “0”


1-1 Without using pressure switch function



1-2 With using pressure switch function




1-3 With using pressure switch function (Stopping when start power supply)




Magnetic pole detection is performed when first starting of motor. after power on.


1-4 Alarm classification




1-5 Alarm classification




1-6 Alarm classification



1-7 Alarm classification



1-8 Alarm classification



Above mentioned condition show when “08” (Indication hold setup of pressure switch) is [1] or [2].

When “08” is [0], it is actual pressure indication.

While stop order by start/stop signal, pressure switch comes to normal state.


Concerning “P12”and “ P13 ” setup, it is possible to change at setup mode. Refer to “(b) Setup mode, of Direction for operating each mode: P23” about its setup range.

Note) In case of alarm classification “1-8 ” as above diagram, pressure switch setup without non-sensitive zone for explanation. Actually, it is setup non-sensitive zone about 0.5Mpa.


2. When the set up item P18 is “1”

When integrated alarm output is used, “warning output” of individual output is used for operation ready output.

2-1 Without using pressure switch function




2-2 With using pressure switch function




It may be precarious condition because of relationship between pressure switch setup and delay time.

2-3 With using pressure switch function (Stopping when start power supply)




Magnetic pole detection is performed when first starting of motor


2-4 Alarm classification




2-5 Alarm classification




2-6 Alarm classification



2-7 Alarm classification



2-8 Alarm classification



Above mentioned condition show when “08” (Indication hold setup of pressure switch) is [1] or [2].

When “08” is [0], it is actual pressure indication.

While stop order by start/stop signal, pressure switch comes to normal state.

Concerning “P12”and “ P13 ” setup, it is possible to change at setup mode. Refer to “(b) Setup mode, of Direction for operating each mode: P23” about its setup range.

Note) In case of alarm classification “2-8 ” as above diagram, pressure switch setup without non-sensitive zone for explanation. Actually, it is setup non-sensitive zone about 0.5Mpa.

【Attached Document : Common for the input signal of the external I/O signal】

As the below figure, cut the jumper wire (JP851) of the terminal basic board in case of using for the outer I/O signal of the input signal common (COM2) as plus common.






Figure: one side of the jumper line is cut and pick up




Figure: cut the jumper line

Method of cutting the jumper wire from the terminal basic board of the noise filter

- (1) Confirm the position of the jumper wire (JP851).
- (2) Cut the one end of the jumper wire, and then lift and pick it up.
- (3) Hold the jumper wire pick up with radio pliers and so on, and cut the end of the other side.

Note) Be careful if the jumper wire is not hold, the jumper wire that scattered will be danger to get into eyes or it may be short-circuit by being caught in the wiring.